

Instructions for use

Before first use of the cleaner, remove the cap from the bottle. Then use a blunt tool to push the spray sieve through the safety foil right into the neck of the bottle as far as it will go.

- **Cleaning:**

The surfaces to be bonded must first be cleaned of heavy dirt. If pipes are to be bonded, follow the instructions given in the Technical Data Sheets of Tangit PVC-U, Tangit PVC-C and Tangit ABS respectively. Now the final cleaning is done using Tangit Cleaner. Spray the cleaner onto a piece of white, non-staining soft paper (e.g. tissue paper from the roll) and thoroughly clean the dry surfaces to be bonded until they are free of grease, dirt and lubricant.

Use a new piece of tissue paper for each cleaning operation. The surfaces cleaned with Tangit Cleaner must be dry before applying the adhesive. Any ice must be removed by careful heating.

- **Bonding:**

For bonding pipes please refer to the instructions given in the Technical Data Sheets of Tangit PVC-U, Tangit PVC-C and Tangit ABS respectively.